

# GOTEK SFR1M44-DU26



The USB drive must be formatted using **FAT32** !

(No exFAT, NTFS, etc.)

## OUT

Red LED turns on and from that moment on all newly written files end up on the USB drive.

Files previously written to the emulator's internal storage are **NOT** copied to the USB drive!

Press again to safely eject the USB drive.  
(Red LED turns off.)

OUT

IN

## IN

Erases the emulator's internal memory and copies the first 1.44 MB of files from the USB drive to the internal storage. Press again to copy the **NEXT** 1.44 MB of files. Repeat until your desired file(s) is/are visible to the device.

The GOTEK SFR1M44-DU26 has an internal storage of 1.44 MB. If no USB drive is connected, this internal storage is visible to and usable by the device. I.e. you can write files to it and read them again. BUT: There's no way to copy files from that internal storage to a USB drive.

Also, when plugging a USB drive and pressing the "IN" button, this internal storage will be erased and filled with files from the USB drive.